

**ROCK  
DOOR<sup>®</sup>**

## Technical Manual

REVISION 9.5



## Rockdoor Styles

Aspen	▶	4
Astoria	▶	5
Arcacia	▶	6
Campus	▶	7
Carolina	▶	8
Classic	▶	9
Classic French Door	▶	10
Colonial	▶	11
Cottage spy view	▶	12
Cottage view light	▶	13
Dakota	▶	14
Diamond	▶	15
Dune Retreat	▶	16
Dune Vision	▶	17
English cottage	▶	18
Georgia	▶	19
Hudson	▶	20
Illinois	▶	21
Indiana	▶	22
Jacobean	▶	23
Kentucky	▶	24
Manhattan	▶	25
Montana	▶	26
Newark	▶	27
Portland	▶	28
Philadelphia	▶	29
Regency	▶	30
Stable diamond view	▶	31
Stable spy view	▶	32
Stable view light	▶	33
Tennessee	▶	34
Tongue and groove 5	▶	35
Vermont	▶	36
Virginia	▶	37
Vogue	▶	38
Vogue French	▶	39
Warwick	▶	40
Windsor	▶	41

### MINIMUM SIZE OVERRIDES

- ▶ Minimum Sash Size Overrides [page 42](#)

### COLOURS

- ▶ Door and Frame Colour [page 44](#)

## Construction Details

### Sections

- ▶ Inner Frame Detail [page 45](#)
- ▶ Stable Door Centre Seal [page 46](#)
- ▶ Double/ French Door Centre Seal [page 47](#)

### Thresholds

- ▶ ALI Threshold Detail [page 48](#)
- ▶ PVC Threshold Detail [page 49](#)
- ▶ Cill Detail [page 50](#)
- ▶ Tie Bar Detail [page 52](#)
- ▶ Sealing a threshold to a cill or tie bar [page 53](#)

### Frame

- ▶ Outer Frame Detail [page 54](#)
- ▶ Add On / Frame Extension [page 55](#)
- ▶ Side Frame Detail [page 56](#)
- ▶ Coupling Bar Detail [page 58](#)
- ▶ Side Frame / Coupling Bar Max Sizes [page 59](#)
- ▶ Side Frame Min Sizes / Transoms [page 61](#)
- ▶ Moulded Panels [page 62](#)
- ▶ Clear Opening [page 63](#)
- ▶ Internal Floor Level Clearance [page 64](#)

### Locks

- ▶ 2 Hook Lock [page 96](#)
- ▶ 4 Hook Lock [page 97](#)
- ▶ AV Options [page 98](#)
- ▶ Electric Latch Release [page 102](#)
- ▶ Switch Latch [page 101](#)
- ▶ Instant Lock Heritage Plus [page 99](#)
- ▶ Cylinder [page 103](#)
- ▶ Emergency Exit Lock [page 105](#)

### Hinge

- ▶ Hinge [page 88](#)
- ▶ Open Out Hinge [page 89](#)

### Lever Handles

- ▶ Standard Lever Handle [page 65](#)
- ▶ Escutcheon v Lever Handle Prep [page 66](#)
- ▶ Stainless Steel Lever Handle [page 67](#)
- ▶ Rose Handle Prep [page 68](#)
- ▶ European Rose Handle [page 69](#)
- ▶ Curved Rose Handle [page 70](#)
- ▶ Twist Lever Handle [page 71](#)
- ▶ Arched Lever Handle [page 72](#)

### Bar Handles

- ▶ In line Bar Handle Details [page 73](#)
- ▶ Offset Bar Handle Details [page 46](#)
- ▶ Mitred Bar Handle Details [page 77](#)
- ▶ Square 1200/900 Bar Handle [page 79](#)
- ▶ Round In Line 600/1200/900 Bar Handle [page 80](#)
- ▶ Square Offset 1200 Bar Handle [page 81](#)
- ▶ Round Offset 1200 Bar Handle [page 82](#)
- ▶ Mitered 900 Bar Handle [page 83](#)
- ▶ Back to Back Fixing Kit [page 84](#)

### Letterplates

- ▶ Standard Letterplate [page 85](#)
- ▶ Stainless Steel Letterplate [page 86](#)
- ▶ TS008 Letterplate [page 87](#)

### Furniture

- ▶ Bull Ring Knocker [page 90](#)
- ▶ Cat Flap [page 93](#)
- ▶ Restrictor Details [page 94](#)
- ▶ Furniture Colour Options [page 95](#)


### Door Pulls

- ▶ Door Pull [page 92](#)
- ▶ Round Knob [page 91](#)

### OTHER INFORMATION

- ▶ Secured By Design [page 108](#)
- ▶ PAS24 [page 106](#)
- ▶ Energy Ratings [page 109](#)
- ▶ Condensation [page 110](#)
- ▶ Replacement Parts [page 115](#)
- ▶ Order Form [page 113](#)
- ▶ Installation Tolerances [page 114](#)

New Forest Texture & 26mm Unit



Door Sash

**Width**

Max: 908mm  
Min: 674mm

**Height**

Max: 2098mm  
Min: 1789mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**

**Width**

**72 Frame**  
Max = (Max sash width + 56mm + 56mm)  
Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
Max = (Max sash width + 36mm + 36mm)  
Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**  
Max = (Max sash height + 56mm + 20mm)  
Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
Max = (Max sash height + 36mm + 20mm)  
Min = (Min sash height + 36mm + 20mm)


**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)  
Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

PRESS GLAZING

UNIT THICKNESS: 26  
UNIT SIZE: 177 x 729  
APERTURE: 140x 690

New Forest Texture & 26mm Unit



Door Sash

**Width**

Max: 908mm  
Min: 740mm

**Height**

Max: 2098mm  
Min: 1942mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**

**Width**

**72 Frame**  
Max = (Max sash width + 56mm + 56mm)  
Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
Max = (Max sash width + 36mm + 36mm)  
Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**  
Max = (Max sash height + 56mm + 20mm)  
Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
Max = (Max sash height + 36mm + 20mm)  
Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)  
Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

PRESS GLAZING

UNIT THICKNESS: 26  
UNIT SIZE: 568 x 468  
APERTURE: 530x 430

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 54](#) ►

PVC-U Thresholds [page 49](#) ►

Ali Thresholds / Tie Bars [page 48](#) ►

Cills [page 50](#) ►

Add On / Frame Extensions [page 55](#) ►



Door Sash

**Width**

Max: 908mm  
Min: 710mm

**Height**

Max: 2098mm  
Min: 1763mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**

**Width**

**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**


Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

**PRESS GLAZING**

UNIT THICKNESS: 22  
 UNIT SIZE: 246 x 668  
 APERTURE: 208x 630

**PRESS BEAD GLAZING**

UNIT THICKNESS: 24  
 UNIT SIZE: 207 x 632  
 APERTURE: 182 x 604



Door Sash

**Width**

Max: 908mm  
Min: 713mm

**Height**

Max: 2098mm  
Min: 1808mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**

**Width**

**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

**Press Glazing**

Unit Thickness: 22  
 Unit Size: 185 X 630  
 Aperture: 148 X 590

**Press Bead Glazing**

Unit Thickness: 24  
 Unit Size: 185 X 630  
 Aperture: 148 X 590

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 54](#) ►

PVC-U Thresholds [page 49](#) ►

Ali Thresholds / Tie Bars [page 48](#) ►

Cills [page 50](#) ►

Add On / Frame Extensions [page 55](#) ►



Door Sash

**Width**

Max: 908mm  
Min: 769mm

**Height**

Max: 2098mm  
Min: 1758mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**Height**

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing

Unit Thickness: 22

Unit Size: 560 X 275


Aperture: N/A

Press Bead Glazing

Unit Thickness: 24

Unit Size: 490 X 225

Aperture: 452 X 192



Door Sash

**Width**

Max: 908mm  
Min: 808mm

**Height**

Max: 2098mm  
Min: 1799mm **Lock override 1893mm**

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing

Unit Thickness: 22

Unit Size: 599 X 1390

Aperture: 565 X 1356

Press Bead Glazing

N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 54](#) ►


PVC-U Thresholds [page 49](#) ►

Ali Thresholds / Tie Bars [page 48](#) ►

Cills [page 50](#) ►

Add On / Frame Extensions [page 55](#) ►





Door Sashes

**Width**

Max:  $908+7+908 = 1823\text{mm}$   
 Min:  $808+7+808 = 1623\text{mm}$

**Height**

Max: 2098mm  
 Min: 1799mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)


**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Bead Glazing

N/A



Door Sash

**Width**

Max: 908mm  
 Min: 729mm

**Height**

Max: 2098mm  
 Min: 1728mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing

N/A

Press Bead Glazing

N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 54](#) ►


PVC-U Thresholds [page 49](#) ►

Ali Thresholds / Tie Bars [page 48](#) ►

Cills [page 50](#) ►

Add On / Frame Extensions [page 55](#) ►

## COTTAGE SPY VIEW



### Door Sash

#### Width

Max: 908mm  
Min: 673mm

#### Height

Max: 2098mm  
Min: 1748mm

#### Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

#### Width

##### 72 Frame

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

##### 52 Frame

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

##### 72 Frame low threshold open IN

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

#### Height

##### 52 Frame low threshold open IN

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

#### Double Door Width 72mm Frame

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

#### Press Glazing

Unit Thickness: 22

Unit Size: 150 X 300

Aperture: 109 X 252


#### Press Bead Glazing

Unit Thickness: 24

Unit Size: 114 X 255

Aperture: 85 X 226

## COTTAGE VIEW LIGHT



### Door Sash

#### Width

Max: 908mm  
Min: 708mm

#### Height

Max: 2098mm  
Min: 1788mm

#### Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

#### Width

##### 72 Frame

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

##### 52 Frame

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

#### Height

##### 72 Frame low threshold open IN

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

##### 52 Frame low threshold open IN

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

#### Double Door Width 72mm Frame

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

#### Press Glazing

Unit Thickness: 22

Unit Size: 485 X 625

Aperture: 436 X 576

#### Press Bead Glazing

Unit Thickness: 24

Unit Size: 440 X 580

Aperture: 410 X 550

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 54](#) ►


PVC-U Thresholds [page 49](#) ►

Ali Thresholds / Tie Bars [page 48](#) ►

Cills [page 50](#) ►

Add On / Frame Extensions [page 55](#) ►

New Forest Texture



Door Sash

**Width**

Max: 908mm  
Min: 679mm

**Height**

Max: 2098mm  
Min: 1768mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**

**Width**


**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)



Door Sash

**Width**

Max: 908mm  
Min: 696mm

**Height**

Max: 2098mm  
Min: 1764mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**

**Width**

**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing

Unit Thickness: 22  
 Unit Size: 320 X 435  
 Aperture: 277 X 371

Press Bead Glazing

N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 54](#) ►


PVC-U Thresholds [page 49](#) ►

Ali Thresholds / Tie Bars [page 48](#) ►

Cills [page 50](#) ►

Add On / Frame Extensions [page 55](#) ►





Door Sash

**Width**  
 Max: 908mm  
 Min: 679mm

**Height**  
 Max: 2098mm  
 Min: 1880mm

Profile Dimensions:  
**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**


**Width**  
**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**  
**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**  
 Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing  
 Unit Thickness: 22  
 Unit Size: 118 X 1518  
 Aperture: 80 X 1480

Press Bead Glazing  
 N/A



Door Sash

**Width**  
 Max: 908mm  
 Min: 679mm

**Height**  
 Max: 2098mm  
 Min: 1880mm

Profile Dimensions:  
**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**

**Width**  
**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**  
**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**  
 Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing  
 Unit Thickness: 22  
 Unit Size: 238 X 1518  
 Aperture: 200 X 1480

Press Bead Glazing  
 N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#)

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 54](#)

PVC-U Thresholds [page 49](#)

Ali Thresholds / Tie Bars [page 48](#)

Cills [page 50](#)

Add On / Frame Extensions [page 55](#)



**Door Sash**  
**Width**  
 Max: 908mm  
 Min: 679mm

**Height**  
 Max: 2098mm  
 Min: 1796mm

Profile Dimensions:  
**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**


**Width**  
**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**  
**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**  
 Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

**Press Glazing**  
 Unit Thickness: 22  
 Unit Size: 192 X 447  
 Aperture: 152 X 413

**Press Bead Glazing**  
 N/A



**Door Sash**  
**Width**  
 Max: 908mm  
 Min: 724mm

**Height**  
 Max: 2098mm  
 Min: 1797mm

Profile Dimensions:  
**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**

**Width**  
**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**  
**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**  
 Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

**Press Glazing**  
 Unit Thickness: 22  
 Unit Size: 512 X 1008  
 Aperture: 462X (752 /961/752)

**Press Bead Glazing**  
 N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#)

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 54](#)


PVC-U Thresholds [page 49](#)

Ali Thresholds / Tie Bars [page 48](#)

Cills [page 50](#)

Add On / Frame Extensions [page 55](#)

New Forest Texture & 26mm Unit



Door Sash

**Width**

Max: 908mm  
Min: 674mm

**Height**

Max: 2098mm  
Min: 1789mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)


Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

PRESS GLAZING

UNIT THICKNESS: 26

UNIT SIZE: 177 x 1627

APERTURE: 140x 1590



Door Sash

**Width**

Max: 908mm  
Min: 768mm

**Height**

Max: 2098mm  
Min: 1808mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing

Unit Thickness: 22

Unit Size: 240 X 1067 (2 Off)

Aperture: 202 X 1030 (2 Off)

Press Bead Glazing

N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#)

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 54](#)

PVC-U Thresholds [page 49](#)

Ali Thresholds / Tie Bars [page 48](#)

Cills [page 50](#)

Add On / Frame Extensions [page 55](#)

**Door Sash****Width**

Max: 908mm  
Min: 768mm

**Height**

Max: 2098mm  
Min: 1808mm

**Profile Dimensions:**

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width****72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height****72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**


Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

**Door Sash****Width**

Max: 908mm  
Min: 753mm

**Height**

Max: 2098mm  
Min: 1801mm

**Profile Dimensions:**

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width****72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height****72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

**Press Glazing**

Unit Thickness: 22

Unit Size: 220 X 910

Aperture: 180 X 866

**Press Bead Glazing**

Unit Thickness: 24

Unit Size: 188 X 875

Aperture: 155 X 842

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 54](#) ►

PVC-U Thresholds [page 49](#) ►

Ali Thresholds / Tie Bars [page 48](#) ►

Cills [page 50](#) ►

Add On / Frame Extensions [page 55](#) ►



Door Sash

**Width**

Max: 908mm  
Min: 768mm

**Height**

Max: 2098mm  
Min: 1801mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing

Unit Thickness: 22

Unit Size: 560 X 912


Aperture: 508 X 867

Press Bead Glazing

Unit Thickness: 24

Unit Size: 516 X 875

Aperture: 482 X 840



Door Sash

**Width**

Max: 908mm  
Min: 679mm

**Height**

Max: 2098mm  
Min: 1800mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing

Unit Thickness: 22

Unit Size: 212 X 212

Aperture: 172 X 172

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 54](#) ►


PVC-U Thresholds [page 49](#) ►

Ali Thresholds / Tie Bars [page 48](#) ►

Cills [page 50](#) ►

Add On / Frame Extensions [page 55](#) ►





Door Sash

**Width**

Max: 908mm  
Min: 684mm

**Height**

Max: 2098mm  
Min: 1797mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing


Unit Thickness: 22

Unit Size: 365 X 862

Aperture: 320 X 819

Press Bead Glazing

N/A



Door Sash

**Width**

Max: 908mm  
Min: 769mm

**Height**

Max: 2098mm  
Min: 1809mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing

Unit Thickness: 22

Unit Size: 547 X 447

Aperture: 512 X 409

Press Bead Glazing

N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 54](#) ►

PVC-U Thresholds [page 49](#) ►

Ali Thresholds / Tie Bars [page 48](#) ►

Cills [page 50](#) ►

Add On / Frame Extensions [page 55](#) ►



Door Sash

Width

Max: 908mm  
Min: 768mm

Height

Max: 2098mm  
Min: 1808mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

Width

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

Height

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing


Unit Thickness: 22

Unit Size: 547 X 1047

Aperture: 512 X 1011

Press Bead Glazing

N/A



Door Sash

Width

Max: 908mm  
Min: 696mm

Height

Max: 2098mm  
Min: 1764mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

Width

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

Height

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing

N/A

Press Bead Glazing

Unit Thickness: 24

Unit Size: 440 X 580

Aperture: 410 X 550

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 54](#) ►

PVC-U Thresholds [page 49](#) ►

Ali Thresholds / Tie Bars [page 48](#) ►

Cills [page 50](#) ►

Add On / Frame Extensions [page 55](#) ►



Door Sash

**Width**  
 Max: 908mm  
 Min: 769mm

**Height**  
 Max: 2098mm  
 Min: 1728mm

Profile Dimensions:  
**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**


**Width**  
**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**  
**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**  
 Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

**Press Glazing**  
 Unit Thickness: 22  
 Unit Size: 230 X 175  
 Aperture: 187 X 140

**Press Bead Glazing**  
 N/A



Door Sash

**Width**  
 Max: 908mm  
 Min: 696mm

**Height**  
 Max: 2018mm  
 Min: 1708mm

Profile Dimensions:  
**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**

**Width**  
**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**  
**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**  
 N/A

**Press Glazing**  
 Unit Thickness: 22  
 Unit Size: 320 X 435  
 Aperture: 277 X 371


**Press Bead Glazing**  
 N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:  
 Minimum Sash Size Overrides [page 42](#)

The overall frame dimensions can be increased or reduced by using other profiles:

- Door Outer Frame [page 54](#)
- PVC-U Thresholds [page 49](#)
- Ali Thresholds / Tie Bars [page 48](#)
- Cills [page 50](#)
- Add On / Frame Extensions [page 55](#)

## STABLE SPY VIEW



### Door Sash

#### Width

Max: 908mm  
Min: 673mm

#### Height

Max: 2018mm  
Min: 1668mm

#### Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

#### Width

##### 72 Frame

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

##### 52 Frame

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

#### Height

##### 72 Frame low threshold open IN

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

##### 52 Frame low threshold open IN

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

#### Double Door Width 72mm Frame

N/A

#### Press Glazing


Unit Thickness: 22

Unit Size: 150 X 300


Aperture: 109 X 252

#### Press Bead Glazing

N/A



## STABLE VIEW LIGHT



### Door Sash

#### Width

Max: 908mm  
Min: 708mm

#### Height

Max: 2018mm  
Min: 1708mm

#### Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

#### Width

##### 72 Frame

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

##### 52 Frame

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

#### Height

##### 72 Frame low threshold open IN

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

##### 52 Frame low threshold open IN

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

#### Double Door Width 72mm Frame

N/A

#### Press Glazing


Unit Thickness: 22

Unit Size: 485 X 625

Aperture: 436 X 576

#### Press Bead Glazing

N/A



Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 54](#) ►

PVC-U Thresholds [page 49](#) ►

Ali Thresholds / Tie Bars [page 48](#) ►

Cills [page 50](#) ►

Add On / Frame Extensions [page 55](#) ►



Door Sash

**Width**

Max: 908mm  
Min: 748mm

**Height**

Max: 2098mm  
Min: 1748mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali** low threshold open **IN** = **20mm**

**Ali** low threshold open **OUT** = **17mm**

**Cill** = **30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**


Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)



Door Sash

**Width**

Max: 904mm  
Min: 688mm

**Height**

Max: 2098mm  
Min: 1768mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali** low threshold open **IN** = **20mm**

**Ali** low threshold open **OUT** = **17mm**

**Cill** = **30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 54](#) ►


PVC-U Thresholds [page 49](#) ►

Ali Thresholds / Tie Bars [page 48](#) ►

Cills [page 50](#) ►

Add On / Frame Extensions [page 55](#) ►





Door Sash

**Width**

Max: 908mm  
Min: 675mm

**Height**

Max: 2098mm  
Min: 1850mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing


Unit Thickness: 22

Unit Size: 200 X 1510

Aperture: 163 X 1472

Press Bead Glazing

N/A



Door Sash

**Width**

Max: 908mm  
Min: 728mm

**Height**

Max: 2098mm  
Min: 1803mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing

Unit Thickness: 22

Unit Size: 510 X 890      510 X 490

Aperture: 466 X 846      466 X 448

Press Bead Glazing

Unit Thickness: 24

Unit Size: 470 X 1852      470 X 455

Aperture: 438 X 818      438 X 422

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 54](#) ►

PVC-U Thresholds [page 49](#) ►

Ali Thresholds / Tie Bars [page 48](#) ►

Cills [page 50](#) ►

Add On / Frame Extensions [page 55](#) ►



Door Sash

**Width**

Max: 908mm  
Min: 675mm

**Height**

Max: 2098mm  
Min: 1850mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing


Unit Thickness: 22

Unit Size: 387 X 1323

Aperture: 352 X 1288

Press Bead Glazing

N/A



Door Sash2

**Width**

Max: 908+7+908 = 1823mm  
Min: 675+7+675 = 1357mm

**Height**

Max: 2098mm

Min: 1850mm **Lock override 1893mm**

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing

Unit Thickness: 22

Unit Size: 387 X 1323

Aperture: 352 X 1288

Press Bead Glazing

N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#)

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 54](#)


PVC-U Thresholds [page 49](#)

Ali Thresholds / Tie Bars [page 48](#)

Cills [page 50](#)

Add On / Frame Extensions [page 55](#)

New Forest Texture & 26mm Unit



Door Sash

**Width**

Max: 908mm  
Min: 769mm

**Height**

Max: 2098mm  
Min: 1897mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)  
Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)  
Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)  
Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**


Max = (Max sash height + 36mm + 20mm)  
Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)  
Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

PRESS GLAZING

UNIT THICKNESS: 26  
UNIT SIZE: 177 x 977  
APERTURE: 140x 940



Door Sash

**Width**

Max: 908mm  
Min: 748mm

**Height**

Max: 2098mm  
Min: 1801mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)  
Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)  
Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)  
Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)  
Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 8mm)  
Min = (Min sash width + Min sash width + 56mm + 56mm + 8mm)

Press Glazing

Unit Thickness: 22  
Unit Size: 530 X 910  
Aperture: 495 X 872

Press Bead Glazing

Unit Thickness: 24  
Unit Size: 495 X 875  
Aperture: 462 X 842

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 42](#)

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 54](#)

PVC-U Thresholds [page 49](#)

Ali Thresholds / Tie Bars [page 48](#)

Cills [page 50](#)

Add On / Frame Extensions [page 55](#)

## Minimum Sash Size Overrides

### 2 Hook Lever Lock and Key Lock

Minimum sash height is 1880mm

Below 1880mm a 3 hook lock will be used (Charged for a 4 hook lock)

### Double Doors

Minimum sash height is 1996mm

Below 1996mm a 3 hook lock will be used (Charged for a 4 hook lock)

### French Doors


Minimum sash height is 1893mm

## Door and Frame Colour

Where the sash and frame meet on the flush side, there is a chamfer on the door which is visible. It is more noticeable when the door and frame are dark colours.


### Open Out Doors with matching sash and frame colours

External View















### Open In Doors with matching sash and frame colours


Internal View



## Door and Frame Colour Options




## Inner Frame Detail






### Stable Door Centre Seal



### French / Double Door Centre Seal





### Threshold Detail


#### Open **IN** Aluminium Threshold

Drip bar and gasket carrier one piece, colour matched to the furniture.

Face fix drip bar with separate gasket carrier, colour matched to the door.



#### Open **OUT** Aluminium Threshold




Gasket Codes	
	R149
	Comes with the carrier
	R149A
	R149B

### Threshold Detail


#### 72mm PVC-U Threshold

A= Face Drainage  
(Slots 5mm x 35mm)  
B= Concealed Drainage




#### 52mm PVC-U Threshold

A= Face Drainage  
(Slots 5mm x 35mm)  
B= Concealed Drainage



If a cill is required on a Rockdoors with a sideframe a reinforced cill **must** be used.

**95mm Cill**  
Art.546360




**Reinforcement**  
Art.251355




50mm x 15mm

**150mm Cill**  
Art.246330



**Reinforcement**  
Art.324971




30mm x 20mm

Face A & Face B used to identify foiled face



If a cill is required on a Rockdoors with a sideframe a reinforced cill **must** be used.

**180mm Cill**  
Art.246340  
Reinforcement 30 x 20





**Reinforcement for BOTH 180mm and 225mm cill**  
Art.324971  
50 x 15  
Reinforcement 30 x 20



30mm x 20mm


**225mm Cill**  
Art.503940  
Reinforcement 30 x 20



Face A & Face B used to identify foiled face


## Tie Bar

### Tie Bar 9mm x 85mm (Max 3m in length)




Aluminium  
Available in Gold and Silver

### Tie Bar 15mm x 114mm (Max 3m in length)




Tie bars can be used with all threshold types and can be positioned to suit the application.

### Examples using an open in low aluminium threshold.




## Sealing a threshold to a cill or tie bar



Silicone position on a double door or a door with sideframes.

The position of the silicone seal is marked in red.




### NOTE:


The full perimeter of the door and under the cill / tie bar must be externally sealed in addition to the sealing listed above.

### Outer Frame Detail

#### 72mm Outer Frame




#### 52mm Outer Frame




### Add On / Frame Extension

#### 45mm Add On / Frame Extension




#### 15mm Add On / Frame Extension




## Side Frame Detail

### 72mm Side Frame



### 52mm Side Frame





## Coupling Bar Detail

### Heavy Weight Coupler (10mm wide)

#### Protruding

Recommended for the higher exposure category. The coupler protrudes this makes it the strongest design of all couplers offered.





CODE	WWL153
IXX (cm)	27.95
IYY (cm)	0.79
DEDUCTION	5mm Per Frame

### Medium Weight Coupler (20mm wide)

#### Flush Fitting

Recommended where a higher exposure category or larger side frames is requested and the couplers remain Flush to the door frame



CODE	WWL106
IXX (cm)	24.5
IYY (cm)	2.4
DEDUCTION	10mm Per Frame





## Coupling Bar Detail

**Light Weight Coupler** (10mm wide)

**Flush Fitting**


Recommended in lower exposure zones and for the narrower side frames.



CODE WWL150  
 IXX (cm) 9.97  
 IYY (cm) 0.40  
 DEDUCTION 5mm Per Frame

**1.5mm Coupler** (1.5mm wide)  
 PVC-U

**Only** use on single door fanlights




CODE PFC70  
 IXX (cm) 0  
 IYY (cm) 10  
 DEDUCTION 0.75mm Per Frame

## Side Frame / Coupling Bar Max Sizes


**72mm Reinforced Outer Frame** to achieve 800PA.

**The door size cannot be larger than 900mm x 2070mm**


**Heavy Duty** (10mm wide)  
 Rigidity : **Very High**



MAX Size with  
**ONE**  
 Sideframe




MAX Size with  
**TWO**  
 Sideframes




MAX Sizes for Side Frames constructed from  
**72mm Reinforced Outer Frame** using **Heavy Duty Coupler**

**The door size cannot be larger than 900mm x 2070mm**


**Medium Duty Coupler** (20mm Wide)  
 Rigidity : **High**



MAX Size with  
**ONE**  
 Sideframe




MAX Size with  
**TWO**  
 Sideframes




MAX Sizes for Side Frames constructed from  
**72mm Reinforced Outer Frame** using **Medium Duty Coupler**

**The door size cannot be larger than 900mm x 2070mm**


**Light Duty Coupler** (10mm wide)  
 Rigidity : **Standard**



MAX Size with  
**ONE**  
 Sideframe



MAX Size with  
**TWO**  
 Sideframes




MAX Sizes for Side Frames constructed from  
**72mm Reinforced Outer Frame** using **Light Duty Coupler**

It is the installers responsibility to ensure that the products are fit for purpose for the environment in which they are installed and the correct level of operational performance is achieved.


## Side Frame / Coupling Bar Max Sizes

52mm Reinforced Outer Frame to achieve 800PA.

**Heavy Duty** (10mm wide)  
Rigidity : **Very High**





The door size cannot be larger than 900mm x 2070mm



MAX Sizes for Side Frames constructed from 72mm Reinforced Outer Frame using Heavy Duty Coupler

The door size cannot be larger than 900mm x 2070mm



**Medium Duty Coupler** (20mm Wide)  
Rigidity : **High**



MAX Sizes for Side Frames constructed from 72mm Reinforced Outer Frame using Medium Duty Coupler

The door size cannot be larger than 900mm x 2070mm

**Light Duty Coupler** (10mm wide)  
Rigidity : **Standard**



MAX Sizes for Side Frames constructed from 72mm Reinforced Outer Frame using Light Duty Coupler

It is the installers responsibility to ensure that the products are fit for purpose for the environment in which they are installed and the correct level of operational performance is achieved.

## Side Frame Min Sizes / Transoms

### Sideframe with MIDRAIL

72mm outer with 105.5 Midrail: **min width =323.5mm**

72mm outer with 69 Midrail: **min width =360mm**

52mm outer with 69 Midrail: **min width =320mm**

### Sideframe with NO Midrail GROOVED

72mm outer: **min width =295mm**


52mm outer: **min width =275mm**

### Sideframe with NO Midrail KNIFED OFF by hand


72mm outer: **min width =190mm**

52mm outer: **min width =190mm**


Standard and the stainless steel option letterplates cannot be fitted into midrails.



**Door T Sash / Midrail 105.5mm**  
Standard Midrail in sideframes  
**Art.546635**



**Slim Transom / Mullion T 69mm**  
Standard Mullion in Fanlights  
**Art.546085**




**Co-extruded Glazing Bead 18.5**  
For 28mm sealed units  
**Art.546572**

DOUBLE MOULDED PANELS

MAX SIZE: w785 x h950


MIN SIZE: w620 x h580




SINGLE MOULDED PANELS

MAX SIZE: w420 x h950

MIN SIZE: w290 x h580



72mm Outer Frame




CLEAR OPENING=  
Door Frame width -194mm

Example:  
A Door frame width of 900mm has a  
clear opening of 706mm

*To comply with Document M, a private or communal entrance  
must have a clear opening greater than 775mm.*

52mm Outer Frame




CLEAR OPENING=  
Door Frame width -154mm

Example:  
A Door frame width of 900mm has a  
clear opening of 746mm

*To comply with Document M, a private or communal entrance  
must have a clear opening greater than 775mm.*

## Internal Floor Level Clearance



### INTERNAL STEP



For **72mm** Profile Sash Width = Overall Frame Width - **112**



For **52mm** Profile Sash width = Overall Frame Width - **72**

## Handle Details




## Standard Lever Handle


### Lever Handle / Escutcheon Prep



### Stainless Steel Handle




#### Important fitting Detail



Insert the spindle so the exposed dish (or spindle groove) as shown in green faces the grub screw. Then tighten the grub screw clockwise to 'splay' the spindle and secure the handle in place.

Doing this **external** and **internal** ensures the handles are secured to the spindle.

## Rose Handle Prep



### Hole position Jig




Its important the jig lines up with the spindle hole on the door.



Its important the jig lines up with the spindle hole on the door.



When everything is lined up, place the pin into the jig and spindle hole to lock the position.




Drill four holes with a 3.2mm drill bit see picture below holding the jig firmly.




You MUST DRILL INTO THE SKIN AND THE ALUMINIUM REPEAT THE PROCESS ON THE OTHER SIDE OF THE DOOR.

## European Rose Handle



### Important fitting Detail





Insert the spindle so the exposed dish (or spindle groove) as shown in green faces the grub screw. Then tighten the grub screw clockwise to 'splay' the spindle and secure the handle in place.


Doing this **external** and **internal** ensures the handles are secured to the spindle.



## Curved Rose Handle



### Important fitting Detail





Insert the spindle so the exposed dish (or spindle groove) as shown in green faces the grub screw. Then tighten the grub screw clockwise to 'splay' the spindle and secure the handle in place.


Doing this **external** and **internal** ensures the handles are secured to the spindle.

## Twist Lever Handle


### Handle Prep



Spring Cassette




### Important fitting Detail




Insert the spindle so the exposed dish (or spindle groove) as shown in green faces the grub screw. Then tighten the grub screw clockwise to 'splay' the spindle and secure the handle in place.

Doing this **external** and **internal** ensures the handles are secured to the spindle.

## Arched Lever Handle



### Important fitting Detail




Insert the spindle so the exposed dish (or spindle groove) as shown in green faces the grub screw. Then tighten the grub screw clockwise to 'splay' the spindle and secure the handle in place.

Doing this **external** and **internal** ensures the handles are secured to the spindle.

## Bar Handle Details


### 600mm, 900mm and 1200mm Fitting Position

#### Vogue



Centred with the glass


#### Vermont



Centred with the glass

Minimum sash width with In line bar handle is **755mm**


#### Indiana



Centred with the mouldings


Minimum sash width with In line bar handle is **820mm**

#### Dakota




Centred with the mouldings

#### Manhattan



Starting datum bottom moulding

#### Hudson



Centred with the glass

### In line bar handles

are fitted **115mm** from the edge of the door to the centre of the fixing hole.

**In Line Bar Handle**

**600mm, 900mm and 1200mm Fitting Position**

**Dune Vision**




Centred with the glass

**Dune Retreat**



Centred with the glass

**Aspen**




Centred with the mouldings

**In line bar handles** are fitted **115mm** from the edge of the door to the centre of the fixing hole.

**Offset Bar Handle**


**900mm and 1200mm Fitting Position**

**Vogue**




Centred with the glass

**Vermont**




Centred with the glass

**Indiana**




Centred with the mouldings

**Dakota**




Centred with the mouldings

**Manhattan**



Starting datum bottom moulding

**Hudson**



Centred with the glass

**Off set bar handles** are fitted **45mm** from the edge of the door to the centre of the fixing hole.

## Offset Bar Handle


### 900mm and 1200mm Fitting Position

Dune Vision




Centred with the glass

Dune Retreat



Centred with the glass

Aspen



Centred with the mouldings


### Off set bar handles

are fitted **45mm** from the edge of the door to the centre of the fixing hole.

## Mitred Bar Handle


### 900mm Fitting Position

Vogue



Centred with the glass


Vermont



Centred with the glass

Minimum sash width with mitred bar handle is **755mm**


Indiana



Centred with the mouldings


Minimum sash width with mitred bar handle is **820mm**

Dakota




Centred with the mouldings

Manhattan



Starting datum bottom moulding

Hudson



Centred with the glass


### Mitred bar handles

are fitted **115mm** from the edge of the door to the centre of the fixing hole.

## Mitred Bar Handle


### 900mm Fitting Position

#### Dune Vision




Centred with the glass

#### Dune Retreat



Centred with the glass

#### Aspen



Centred with the mouldings



### Mitred bar handles

are fitted **115mm** from the edge of the door to the centre of the fixing hole.

## Square Bar 1200mm / Square Bar 900mm

SIZE: 1200 Bar Handle  
 A=1200mm  
 B=1000mm  
 C=100mm

SIZE: 900 Bar Handle  
 A=900mm  
 B=700mm  
 C=100mm





Section A-A

## Round Bar 600mm, 900mm and 1200mm



SIZE:600mm  
A=600mm  
B=400mm  
C=100mm

SIZE:900mm  
A=900mm  
B=700mm  
C=100mm

SIZE:1200mm  
A=1200mm  
B=1000mm  
C=100mm



SIZE:  
A=1200mm  
B=1000mm  
C=100mm





## Square Bar 1200mm (Offset)




## Round Bar 1200mm (Offset)


SIZE:  
**A=1200mm**  
**B=1000mm**  
**C=100mm**



SIZE:  
**A=930mm**  
**B= 900mm**



## Mitre Bar 900mm



## Back to Back Fixing Kit


### Fitting Instructions

(Do the same on the top and the bottom fixing position)


The metal washers can be used if required they fit between the brass ferrules and the Rockdoor.

**1.** From the inside slide the non threaded brass ferrule over the fixing bolt so the counter sunk head fits into the counter sink of the ferrule.


Slide the 8mm fixing bolt through the pre drilled hole in the Rockdoor.




**2.** Screw the threaded ferrule to the fixing bolt from the outside.



**3.** Fit the handles in position



**4.** Tighten all the grub screws to secure.




## Letterplate

### Standard Letterplate

Meets the requirements of BS EN 1670:2007 Grade 5 (480 hours)

Flap cycle tested to 30,000 cycles Conforms to the requirements of BS EN 13724: 2002

Zinc construction with hardex coating.




### Stainless Steel Letterplate

Cycle tested to 20,000 cycles


Corrosion tested in excess of 1,000 hours based on BS EN 1670

304 stainless steel construction




### Stainless Steel Contemporary Letterplate

- Achieved 'Best in Class' BS6375-1 Weather Test results against air, wind and water.  
Weather Test : Air Permeability: Class 4, Water Tightness: Class A9, Wind Resistance: Class 5
- Integral gaskets, brushes and telescopic liner for enhanced weather and draught protection.
- Built-in inner security flap helps prevent 'fishing'.
- Manufactured from 316 Grade Stainless Steel.
- Ideal for use where corrosion levels are high such as coastal environments.



### Aperture Detail




### Fitting in the bottom rail

Check online using the portal as it is sash height dependant.

Not available under the glass on the Georga, the Montana and the Newark.


### TS008 Letterplate

- Cycle tested to 20,000 cycles
- Corrosion tested in excess of 1,000 hours based on BS EN 1670
- White PVC-U internal
- 304 stainless steel construction external
- Concealed hinge mechanism for attack resistance



### Sideframe Letterplate

- 180 Opening
- Black plastic frame
- Aperture size 247mm x 28mm







# Hinge

## Rockdoor Standard Hinge

Adjustable using a 4mm allen key.

Up/Down +/-3mm In/Out +/-2mm

Left/Right +/-2mm







## Open Out Hinge

Adjustable using a 4mm allen key.

Up/Down +/-3mm In/Out +/-2mm

Left/Right +/-2mm




Open-out doors are fitted with concealed grub screws. The grub screws engage into a groove in the hinge pin; this stops the hinge pin from being removed. The grub screws are only accessible when the door is in the open position.




# Open Out Hinge

## Bull Ring Knocker


### Stainless Steel Bull Ring Knocker




### Bolt through fixing



### Fitting Positions




All measurements are taken from the moulding to the centre line of the top hole.




## Round Knob

### Stainless Steel Knob



### Fitting Positions 10mm Diameter Hole







## Door Pull

### Stainless Steel Door Pull

#### External



#### Internal



ROCK  
DOOR



## Cat Flap



### Magnetic Cat Flap Available in White and Brown

#### Magnetic Lock

The magnetic operation requires no batteries the cat simply wears a collar key which is then used to open the locking mechanism of the cat door. Although not 100% secure (no cat flap is) this does help to keep out unwanted strays and other small animals.

#### 4-way Locking

The 4-way latch offers the ultimate in flexibility. Set the cat flap to open, closed, in only or out only.



### Manual Cat Flap Available in White and Brown


#### 4-way Locking

The 4-way latch offers the ultimate in flexibility. Set the cat flap to open, closed, in only or out only.

### Door Styles available with a cat flap:

- Aspen
- Stable spy view
- Stable view light
- Cottage spy view
- Cottage view light
- T & G 5
- Indiana
- Dakota

### Cut out positions





## Restrictor Detail



### AV-SLDR-A Open Out Restrictor

Door restrictors are designed to provide adjustable limitation to the door movement and allow an opening aperture of maximum 90°.


Features and Specifications:

- Tested to 100,000 cycles
- Corrosion resistance Grade 4 in accordance with BS EN1670:1998

Top edge of door machined off 3.7mm to allow for the restrictor arm.



Installed 100mm from the corner of the frame on the hinge side.





## Furniture Colour Options





Polished chrome matches polished stainless.  
Polished gold matches gold stainless.  
Graphite matches brushed stainless.  
Midnight black, black stainless and wrought iron are all slightly different in colour finish.


	Polished Chrome	Graphite	Polished Gold	Midnight Black	White	Wrought Iron	Brushed Stainless	Polished Stainless	Black Stainless	Gold Stainless
Lever Handle	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Pad Handle	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
D Handle	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Twist Lever Handle	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Arched Lever Handle	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
European Rose Handle	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Curved Rose Handle	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Finger Pull	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Escutcheon	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Standard Letterplate	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Stainless Letterplate	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
TS008 Letterplate (Matching)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Sideframe Letterplate (Black outer)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Contemporary Letterplate	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Victorian Centre Knob	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Urn Knocker	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Spy View	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Architectural Knocker	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Numerals	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Contemporary Numerals	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Bull Ring Knocker	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Square Centre Knob	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Round Bar Handle 600 900 1200	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Offset Round Bar Handle 1200	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Square Bar Handle 1200	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Square Bar Handle 900	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Offset Square Bar Handle 1200	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Mitred Bar Handle 900	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Yale Latch	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Yale Finger Pull	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Slide Bolt	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Door Chain	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Hinges	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Cylinder	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Cylinder with thumbturn	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓



**Drawing Description:**  
Dimensional Details Of Winkhaus' Standard STV Two Hook Residential Multi-point Door-lock System on a F20 rail.



**Drawing Description:**  
Dimensional Details Of Winkhaus' Standard STV Four Hook Residential Multi-point Door-lock System on a F20 rail.



When the door closes this pin is pushed back which throws the hooks out instantly securing the door from the outside.

### AV2 with Lever/ Fixed D Handle

#### Locking from the inside

- Closing the door automatically throws the top and bottom hooks making the door instantly weathered and secure from the outside.
- The handle can still be operated from the inside for instant exit.
- Insert the key and rotate one revolution to deadlock the door. This throws the central deadbolt and blocks the handle from operating. The door is now fully weathered and secure.

#### Unlocking from the inside

- Insert the key and rotate one revolution. This retracts the central deadbolt and allows the handle to be operated. The door remains weathered and secure from the outside.
- Depress the handle to retract the top and bottom hooks and open the door.

#### Locking from the outside

- Closing the door automatically throws the top and bottom hooks making the door instantly weathered and secure.
- Insert the key and rotate one revolution to deadlock the door. This throws the central deadbolt and blocks the internal handle from operating. The door is now fully weathered and secure.

#### Unlocking from the outside

- Insert the key and rotate one revolution. This retracts the deadbolt.
- Turn the key a further 45 degrees to retract the top and bottom hooks and open the door.

### Instant Lock Heritage Plus

Cylinder height centre is 1395mm from the bottom of the door sash.

The lock mechanism has 2 hooks, a central latch and a high-level cylinder position.

This is fitted with either a finger pull, or an escutcheon and a thumbturn internally.

The magnetic triggering of the automatic locking reduces stress marks on the door frame and dampens the closing noise of the automatic locking system.

The magnetic trigger and hook design also improves the reliability of the product, as it can work with slightly larger tolerances which can accommodate any slight door/frame movement over time.

#### Instant Locking

The Heritage plus system is an instant multi-point locking system with independently acting hooks.

The action of closing the door fully secures the door. There is no further action needed to lock the door.

To open the door the hooks and latch are retracted manually using a key or thumbturn, you are only required to turn a quarter of a turn.

#### Magnetic Switch Latch. (Different to standard switch latch)

##### UP position


When the switch latch is in the **UP** position, the door instantly locks upon closing. A key is required to regain entry to the property. The door can be opened internally with the thumbturn.

##### DOWN position

When the Switch Latch is in the **DOWN** position, no key is required allowing you to regain entry to the property and the door can open or close freely.

The door cannot be locked with a key or thumb-turn when the switch latch is in the down position. To lock the door move the switch latch into the up position and then close the door to lock.

Routing details for Instant Lock Heritage plus



Up Position

When the Switch Latch is in the **UP** position a key is required to gain entry to the property. Don't get caught out and **lock yourself out**.

For total security, the key or thumbturn still needs fully engaging to ensure the hook locks are secured in place.



Down Position

When the Switch Latch is in the **DOWN** position no key is required allowing you to gain entry to the property and the door can **open or close freely**.

For total security, the key or thumbturn still needs fully engaging to ensure the hook locks are secured in place.







Unlike the magnetic switch latch fitted to the Heritage Plus lock the door can be locked in the down position.

## Electric Latch Release

Fail **SAFE** Electric Latch Release  
(no power)

Fail **SECURE** Electric Latch Release  
(no power)




### Technical Details (for Both Options)

Handing	Universal
potential	12 V DC
Adjustable latch (FF, FaFix®)	Yes
Fail-unlocked	Yes
Rated operating voltage tolerance range	± 1 V
Rated resistance	60 Ohm
Current consumption DC (50% Residual ripple)	225 mA
Current consumption DC (stabilised)	200 mA
Break-in resistance	3000 N
Height	90 mm
Width	16 mm
Operating temperature range	-15 °C to +40 °C
Max. keeper pre-load DC (50% residual ripple)	10 N
Max. latch preload DC (stabilised)	10 N
Depth	28 mm
Material housing	Zinc die-cast
Latch material	Zinc die-cast
Material surface-mounted attachment	MESSING

## Cylinder

### 3 Star Cylinder









The cylinder must be installed with the sacrificial section to the external of the property.

#### FEATURES:

- SS312 Sold Secure Diamond Grade
- 3 Star British Kitemark - TS007:2014 (KM 586153)
- Secured by Design Accredited (Police preferred specification)
- Patented Snap Secure Technology
- Pick, Drill & Bump Resistant
- 6 Trap Pins for advance pick resistance
- 10 Anti-drill pins
- Three Rockdoor branded keys per cylinder
- Keyed alike key/key pairs are available ex stock
- Size 40mm/40mm

The key must be removed from the cylinder for the full security features to be enabled.





Emergency Exit Door

Rockdoors emergency exit door is customised with a hardware solution that allows the door to be opened quickly and easily in a 'panic' situation. This includes typical emergency exits used in public places such as shopping centres, schools, cinemas and commercial use buildings.



External Operation

**Lock:** To lock the door from the outside, the key provided must be used to wind out the bolts into position. If the door is locked from the inside the external handle will not open the door.

**Unlock:** To open the door from the outside, use a key to unwind the bolts and then open the door using the external lever handle.



Internal Operation

**Lock:** To lock the door from the inside, use the thumbturn to wind out the bolts.

**Unlock:** To open the door from the inside, push firmly down on the push bar which will instantly retract the locks and allow the door to open freely. This will open the door regardless of whether the door has been left in the locked or unlocked position.

High Security, Quick Escape

Our emergency exit door ensures buildings can remain extremely secure, whilst providing a quick and safe method of exit to members of the public.

When to use Emergency Exit Doors

In accordance with EN1125, Rockdoor emergency exit doors should be used as a single door set that members of the public will have access to. The high concentration of people makes 'panic' situations more likely in public buildings. The occupants will not necessarily be familiar with the locations of the emergency exits, or how to open them. They therefore need to be able to open the doors intuitively using the horizontal push bar.

Rockdoor emergency exit doors, in accordance with EN 1125, are always outward-opening doors. All emergency exit doors must bear the CE mark.

**Door Specification:****1. Door styles**

All door styles except stable doors and double doors.

**2. Glazing**

P1A compliant glass (6.8mm Laminated)

**3. Outer frame**

72mm Rehau Outer frame or 52mm Rehau Outer frame

**4. Reinforcing**

Security Mesh

**5. Handle**

Standard lever/lever handle or Bar Handle

**6. Hinges**

Standard 3D Rockdoor hinge

**7. Lock**

Winkhaus 2 hook lock

**8. Cylinder**

Standard Rockdoor 3 star cylinder

**9. Keeps**

Standard Rockdoor full length keeps

**10. Threshold**

Aluminium low threshold

**11. Letterplate**

Must be TS008 compliant

**Methods of test.****1. Operating Forces**

The operating forces acting on the sample were determined by the methods given in BS EN 12046-2:2000.

**2. Air Permeability**

The air permeability of the sample was determined by the method given in BS 6375-1:2015.

**3. Watertightness**

The watertightness of the sample was determined by the method given in BS 6375-1:2015.

**4. Wind Resistance**

The wind resistance of the samples was determined by the methods (P1 and P2) given in BS 6375-1:2015.

**5. Repeat Tests**

After testing for resistance to wind loading (P1 and P2) the air permeability test was repeated.

**6. Wind Resistance**

The wind resistance of the samples was determined by the method (P3) given in BS 6375-1:2015.

**7. Resistance to Vertical Loads**

The resistance to vertical loads test was carried out using the method given in BS EN 947:1999.

**8. Resistance to Static Torsion**

The resistance to static torsion test was carried out using the method given in BS EN 948:1999.

**9. Soft and Heavy Body Impact**

The resistance to soft and heavy body impact was carried out using the method given in BS EN 949:1999.

**10. Hard Body Impact**

The resistance to hard body impact was carried out using the method given in BS EN 950:1999.



Secured by Design (SBD) is the official police security initiative that works to improve the security of buildings and their immediate surroundings to provide safe places to live.

For Rockdoor to meet the specification they should be fitted with:

- 1 **P1A Compliant glass (6.8mm laminated)**
- 2 **Security mesh.**
- 3 **Letterplates must conform to requirements of TS008.**



For solid door styles with no glass, please refer to the Clear Backing glass section for the doors energy rating

Door Style

Door Style	CLEAR BACKING GLASS				OBSCURE BACKING GLASS			
	72mm threshold	52mm threshold	Alii threshold open out	Alii threshold open in	72mm threshold	52mm threshold	Alii threshold open out	Alii threshold open in
Aspen	A	A	A	A	A	A	A	A
Astoria	A	A	A	A	A	A	A	A
Arcacia	A	A	A	A	A	A	A	A
Campus	A	A	A	A	A	A	A	A
Carolina	A	A	A	A	A	A	A	A
Classic	B	B	B	B	B	B	B	B
Colonial	A	A	A	A				
Cottage spy view	A	A	A	A	A	A	A	A
Cottage view light	A	A	A	A	A	A	A	A
Dakota	A	A	A	A				
Diamond	A	A	A	A	A	A	A	A
Dune Retreat	A	A	A	A	A	A	A	A
Dune Vision	B	B	B	B	B	B	B	B
English cottage	A	A	A	A	A	A	A	A
Georgia	B	B	B	B	B	B	B	B
Hudson	A	A	A	A	A	A	A	A
Illinois	B	B	B	B	B	B	B	B
Indiana	A	A	A	A				
Jacobean	B	B	B	B	B	B	B	B
Kentucky	B	B	B	B	B	B	B	B
Manhattan	A	A	A	A	A	A	A	A
Montana	A	A	A	A	A	A	A	A
Newark	A	A	A	A	A	A	A	A
Portland	B	B	B	B	B	B	B	B
Philadelphia	A	A	A	A	A	A	A	A
Regency	A	A	A	A	A	A	A	A
Stable diamond view	B	B	B	B	B	B	B	B
Stable spy view	B	B	B	B	B	B	B	B
Stable view light	B	B	B	B	B	B	B	B
Tennessee	B	B	B	B	B	B	B	B
Tongue and groove 5	A	A	A	A	A	A	A	A
Vermont	A	A	A	A	A	A	A	A
Virginia	B	B	B	B	B	B	B	B
Vogue	B	B	B	B	B	B	B	B
Warwick	A	A	A	A	A	A	A	A
Windsor	B	B	B	B	B	B	B	B

## WHAT CREATES CONDENSATION?

### Water vapour content in the air

This is produced by normal living activities such as washing, cooking, bathing, etc., and can be controlled using extractor fans, cowlings, and ventilation at appropriate places.

### Inside room temperature

This can be controlled to some extent, thereby maintaining a higher surface temperature of items in the room, and by increasing the air temperature to enable it to hold more water vapour without condensing.

### Coldest surface in the home

Modern aids to home comfort have created rooms which are warmer, but which often have less ventilation and fewer air changes. The result is that the water vapour produced by normal living activities, is no longer able to escape up the chimney or through door jambs, window joints and other outlets.

In certain circumstances, all these aids to comfort combine to create ideal conditions for the formation of condensation, which could form on the coldest surfaces within the home.

### What is the coldest part of a Rockdoor.

Thermally efficient PVC-U skins, a 50mm thick sash, S-Glaze, performance gaskets, Multi chamber PVC-U door frame and high-density polyurethane foam work together to achieve industry leading thermal performance ratings.

However, there are areas on a Rockdoor that when the outside temperatures are low can be colder than other areas, especially if the internal temperatures are also low.

These areas are the locking cylinder, the hinges, Aluminium thresholds, and the area where the aluminium reinforcement is inside the door (around the perimeter).

If the conditions for condensation are present, it can start to appear on the above parts of the door.

## Examples of where water vapour comes from

**Breathing:** Two sleeping adults produce approximately 1 litre of moisture in 8 hours, which is absorbed as water vapour into the atmosphere.

**Cooking:** Steam clouds can be seen near saucepans and kettles, and then seem to disappear. The clouds have been absorbed into the atmosphere. The heat source itself may be a source of water vapour, e.g. an average gas cooker could produce approximately 1 litre of moisture per hour.

**Washing up:** Vapour clouds given off by hot water are rapidly absorbed into the atmosphere. Bathing, laundry, and wet outer clothing: these are often major sources of water vapour in the home.

**Heaters:** A flueless gas heater can produce up to 350cc of moisture per hour. Paraffin heaters produce 4 litres of moisture for every 3.5 litres of fuel burned.

**Indoor plants:** A frequently unrecognised but nevertheless significant source of water vapour.

**New property/building work:** The bricks, timber, concrete, and other materials in an average 3-bedroomed house absorb about 7,000 litres of water during construction. Much of this is dissipated into the indoor atmosphere during the drying out period.

## How do you reduce the condensation in the home?

- It is important to remove excess moisture by ventilating rooms.
- A room can be ventilated without making draughts or causing it to become cold. One way to do this is to open the window slightly or use the trickle vent if fitted.
- By opening windows or ventilating your home it may appear that you are losing some heat, but what you are doing is allowing warm moisture laden air to escape and permitting cool dry air to enter your home. Dry cool air is cheaper to heat than warm moist air.
- Provide natural ventilation through an opening section of the window, through a proprietary ventilating unit, or through an airbrick. Check that trickle vents are in the open position.
- Where there is no open fire, or where existing flues have been blocked off (and cannot be unblocked), ensure that wall vents are fitted and kept clear.
- Open at least one window in each room for some part of the day to permit a change of air. Ensure permanent ventilation of all rooms where gas and oil heaters are used. NOTE: This is a statutory requirement which will be monitored by the heating engineer.

- Fix hoods over cookers and other equipment producing steam and ventilate them to the outside air.
- Ensure that bathrooms and kitchens are ventilated in accordance with National Standards.
- Draught proof internal doors and keep them closed, to prevent transfer of air with high water vapour content from the main moisture producing rooms –kitchens, bathrooms, and drying rooms. It should be borne in mind that water vapour does not remain in the room where it is first generated but tends to migrate to other parts of the home generally where the rooms are colder.
- Increase slightly the air temperature within the room where the condensation occurs.
- In cold weather, keep some form of heating on permanently in the room where the condensation occurs.
- In winter months to help with atmospheric moisture control the introduction of a dehumidifier will help maintain a healthy living space and help reduce the chances of condensation forming on cooler surfaces.

Summary

Whilst we pride ourselves on creating a thermally efficient industry leading door, it is important we raise awareness to customers on the issues experienced by all window and door manufacturers. The nature of modern-day living has created cosy warm homes where moist damp air is stored, but it is this damp air that manifests itself as condensation unless the air is dealt with and removed from the property. This issue is highlighted by the government's building regulations that now stipulate the use of trickle vents on all newly installed windows, both in new build house and replacement windows.

ROCKDOOR ORDER FORM



Please complete all the sections or go to [www.gap.uk.com](http://www.gap.uk.com) and order online.

For Office Use Only

SURVEY DETAILS (VIEWED OUTSIDE)		YOUR DETAILS	
Overall Width (inc add ons)	.....	Company Name	.....
Overall Height (inc add ons & Cill)	.....	Account No	.....
Opens In <input type="checkbox"/> Out <input type="checkbox"/>	Outer frames are not available in all colours for open out doors. Please refer to technical manual on our website.	Contact	.....
Hinged Left <input type="checkbox"/> Right <input type="checkbox"/> Double Doors <input type="checkbox"/>	For French Doors please use alternative order form.	Phone	.....
Cill None <input type="checkbox"/> Dummy <input type="checkbox"/> 95 <input type="checkbox"/> 150 <input type="checkbox"/> 180 <input type="checkbox"/> 85 TIE BAR <input type="checkbox"/> 114 TIE BAR <input type="checkbox"/>		Fax or E-mail	.....
Aluminium Threshold <input type="checkbox"/>	The base section matches the colour of the furniture. With black furniture it will be silver.	Reference No	.....
Slim PVC 52 Threshold <input type="checkbox"/>		Order No	.....
Large PVC 72 Threshold <input type="checkbox"/>	Drip bar as standard will match the door colour.	Order Date	...../...../..... Date Req...../...../.....
Drip Rail Match to furniture <input type="checkbox"/> Match to door <input type="checkbox"/>		Site Address	.....
Frame add ons 15mm <input type="checkbox"/> Position .....			
2 x 15mm <input type="checkbox"/> Position .....			
45mm <input type="checkbox"/> Position .....			
		Number of Attached Sheets <input type="text"/>	

ROCKDOOR DETAILS															
Door Style	.....														
Frame Size	72mm (standard) <input type="checkbox"/>					52mm (slim) <input type="checkbox"/>									
	White	Onyx Black	Anthracite Grey	Smooth Anthracite Grey	Slate Grey	Agate Grey	Pebble Grey	Chartwell Green	Cream	Ruby Red	Emerald Green	Sapphire Blue	Rosewood	Light Oak	Irish Oak
Door External	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Door Internal	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Frame External	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Frame Internal	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

ROCKDOOR GLASS		SIDE FRAME / FANLIGHT GLASS	
Glass Design	.....	Backing Glass	.....
Backing Glass	.....	(Clear Low E & Argon Filled is Standard)	

ROCKDOOR SECURITY			
Lever lock	2 Hook (std) <input type="checkbox"/>	4 Hook <input type="checkbox"/>	Nightlatch <input type="checkbox"/>
Key lock	2 Hook with escutcheon <input type="checkbox"/>	2 Hook with finger pull <input type="checkbox"/>	
Instant lock	Heritage plus with finger pull <input type="checkbox"/>	Heritage plus with escutcheon <input type="checkbox"/>	AV2 <input type="checkbox"/> AV2E only available with fixed D handle <input type="checkbox"/>
Stable door lock	2 Hook <input type="checkbox"/>	(Only option available with a stable door)	
Spindle	Full Spindle <input type="checkbox"/>	Split Spindle (only available with a standard handle/lock) <input type="checkbox"/>	(Split Spindle not available on a stable door)
Cylinder	Key/Key (std) <input type="checkbox"/>	Key / Thumbturn <input type="checkbox"/>	Secure By Design <input type="checkbox"/> Includes laminated glass, security mesh and TS008 letter plate.
Extra security	Mesh Reinforcing <input type="checkbox"/>	Security Chain <input type="checkbox"/>	

HANDLE	
<b>Lever Handle</b>	<b>Stainless steel Bar Handle</b>
Standard Lever/Lever <input type="checkbox"/>	Round 1200 <input type="checkbox"/>
Standard Lever/Pad <input type="checkbox"/>	Round 900 <input type="checkbox"/>
	Round 600 <input type="checkbox"/>
Stainless Steel Lever <input type="checkbox"/>	Round Offset 1200 <input type="checkbox"/>
Curved Rose Handle <input type="checkbox"/>	Square 1200 <input type="checkbox"/>
European Rose Handle <input type="checkbox"/>	Square Offset 1200 <input type="checkbox"/>
Wrought Iron Arched lever <input type="checkbox"/>	Mitred 900 <input type="checkbox"/>
Wrought Iron Twisted lever <input type="checkbox"/>	Black Square 900 <input type="checkbox"/>

LETTER PLATE						
	Polished Gold	Polished Chrome	Midnight Black	Graphite	White	Stainless Steel
Standard	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Contemporary	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Stainless Steel	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
TS008	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Fitting position	Midrail <input type="checkbox"/>	Bottom <input type="checkbox"/>	Loose <input type="checkbox"/>			

**NOTE:** The letter plate colour will determine all the main furniture colours.  
If stainless steel is selected The furniture colour will be silver where stainless steel is not available.

FURNITURE					
<b>Main Furniture Colour</b>	Polished Gold	Polished Chrome	Graphite	Midnight Black	White
Including standard handle only	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Urn Knocker	Mullion <input type="checkbox"/>	Loose <input type="checkbox"/>			
Architectural Knocker	Mullion <input type="checkbox"/>	Loose <input type="checkbox"/>			
Spy Hole	Mullion <input type="checkbox"/>	Loose <input type="checkbox"/>			
Spy/Urn Knocker	Mullion <input type="checkbox"/>	Loose <input type="checkbox"/>			
Round Centre Knob	External <input type="checkbox"/>	External & internal <input type="checkbox"/>			
Numerals .....	Top <input type="checkbox"/>	Loose <input type="checkbox"/>			
<b>Stainless Steel Furniture</b>					
Contemporary Knocker Stainless Steel	Mullion <input type="checkbox"/>	Loose <input type="checkbox"/>			
Square Centre Knob Stainless Steel	External <input type="checkbox"/>	External & internal <input type="checkbox"/>			
Bull Ring Knocker	Mullion <input type="checkbox"/>	Loose <input type="checkbox"/>			
Stainless Steel Numerals .....	Top <input type="checkbox"/>	Loose <input type="checkbox"/>			

ARTWORK	
Drawing is for illustration purposes only. Items such as hinge side, furniture position will be processed from the tick box selected.	For sketching fan lights or side frames only.
Double doors ordered on this form will have a fixed slave door. For French Doors please request a French Door order form.	
Specify door width if ordering sideframes	
Door Width	.....
Side/Frame Width	.....
Midrail/Transom Height	.....

**NOTE:**  
 • We match the furniture colours as close as possible but due to materials they are not always identical.  
 • Cylinders are available in silver and gold.  
 • If there is no black furniture option available we will replace it with chrome.  
 • All centre knobs are silver.

Index pages 2-3

To ensure the door functions as required, the following must be met.

**Single door, Stable door, French doors and Double doors**

**HEAD GAP**

The head gap should be 4mm and parallel the full width of the door.  
Tolerance +/- 1mm

**LOCK SIDE GAP**

The lock side gap should be 4mm and parallel the full height of the door.  
Tolerance +/- 1mm

**VIEWING GAP**

The viewing gap should be parallel the full height of the door.  
Tolerance +/- 1mm

**Heritage Plus and all doors with AV Locks fitted**

**HEAD GAP**

The head gap should be 4mm and parallel the full width of the door.  
Tolerance +/- 0.5mm

**LOCK SIDE GAP**

The lock side gap should be 4mm and parallel the full height of the door.  
Tolerance +/- 0.5mm

**VIEWING GAP**

The viewing gap should be parallel the full height of the door.  
Tolerance +/- 0.5mm


Rockdoor must be installed in-line with the five star installation guide.

**Replacement Parts**

To ensure you receive the correct replacement part, you firstly need to find the Rockdoor production number of the door that requires parts. This can be found on the hinge side of the inner frame and is a 6 or 7 digit reference number. Contact can then be made to GAP's customer service team ([customerservice@gap.uk.com](mailto:customerservice@gap.uk.com)) who can help you.

Our team can then use our systems to find the correct part for the door and arrange for its delivery to the depot.

With lots of parts used to construct the door, it's useful to make sure we have the correct part, so please refer to the illustration below.





The Original **Composite Door**.

Rockdoor must be installed in-line with the five star installation guide. ★★★★★